




LINSY 林氏家居

安装示意图/Assembly Instruction

产品名称 Model NO.	ZH2M-A 2.4米高脚电视柜
产品规格 Specification	2357*398*520mm
安装工具 Tool	安装人数 Installer



注：为保证设计效果，部分尺寸为定制尺寸，不影响使用。




五金表/Hardware list

(A) *76 二合一螺杆 2-in-1 screw	(B) *76 大三合一锁饼 3-in-1 large lock	(C) *27 木榫88x30mm Wood tenon	(D) *2 三节滚珠导轨10" (DTC) Three-section rail
(E) *51 自攻螺丝M3.5*14mm Tapping screw	(F) *16 层板托5mm shelf support	(G) *2 穿线孔盖 Threading cover	(H) *6 灰色毛毡垫(直径25*3mm) Foot pad
(I) *4 缓冲门较大弯-杯径835 Great bend hinge	(J) *6 锤母M8*15 Hammer nut	(K) *6 斜边内六角螺栓-M8x50 Beveled hexagon socket head screw	(L) *1 内六角扳手5mm Hexagon wrench
(M) *8 小角码-(14*21*1.5mm) Small bracket	(N) *2 消音磁碰 Magnetic catch		

部件表/Parts List

编号NO.	名称Name	规格(mm) Specification	数量QTY	材质Material
①	面板Top panel	2357*398*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
②	底板Bottom board	2357*398*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
③	左右侧板Left and right side panels	337*397*15	2	无醛定向刨花板 Aldehyde-free directional particleboard
④	左中侧板Middle side board(L)	337*363*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
⑤	中中侧板Middle side board	337*309*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
⑥	右中侧板Middle side board(R)	337*363*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
⑦	脚组立Leg assembly	150*357*45	3	无醛定向刨花板 Aldehyde-free directional particleboard
⑧	立水Standing water	1011*50*15	2	无醛定向刨花板 Aldehyde-free directional particleboard
⑨	背板1Back board 1	534*337*15	2	无醛定向刨花板 Aldehyde-free directional particleboard
⑩	背板2Back board 2	1227*337*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
⑪	左门板组立Door board assembly(L)	530*333*30	1	无醛定向刨花板+橡胶木 Aldehyde-free directional particleboard+Rubber wood
⑫	右门板组立Door board assembly(R)	530*333*30	1	无醛定向刨花板+橡胶木 Aldehyde-free directional particleboard+Rubber wood
⑬	左抽屉面板组立Drawer's board assembly(L)	610*333*30	1	无醛定向刨花板+橡胶木 Aldehyde-free directional particleboard+Rubber wood
⑭	右抽屉面板组立Drawer's board assembly(R)	610*333*30	1	无醛定向刨花板+橡胶木 Aldehyde-free directional particleboard+Rubber wood
⑮	抽屉侧板Drawer's sideboard	290*206*15	4	无醛定向刨花板 Aldehyde-free directional particleboard
⑯	抽屉后板Drawer's Back board	580*206*15	2	无醛定向刨花板 Aldehyde-free directional particleboard
⑰	抽屉底板Drawer's Bottom board	560*300*5	2	ENF级纤维板 ENF grade fiberboard




编号NO.	名称Name
①	面板Top panel
②	底板Bottom board
③	左右侧板Left and right side panels
④	左中侧板Middle side board(L)
⑤	中中侧板Middle side board
⑥	右中侧板Middle side board(R)
⑦	脚组立Leg assembly
⑧	立水Standing water
⑨	背板1Back board 1
⑩	背板2Back board 2
⑪	左门板组立Door board assembly(L)
⑫	右门板组立Door board assembly(R)
⑬	左抽屉面板组立Drawer's board assembly(L)
⑭	右抽屉面板组立Drawer's board assembly(R)
⑮	抽屉侧板Drawer's sideboard
⑯	抽屉后板Drawer's Back board
⑰	抽屉底板Drawer's Bottom board

ZH2M-A 2.4米高脚电视柜


安装方法/ Installation method

阀门开关(下压为开)
Valve switch
(press down to open)





注: 先将A与B拆下来
Note: remove a and B first

侧板
side board




抽屉侧板
sideboard
of the drawer



注: 将B对准A后推进去
Note: align B with a
and push it in


三节滚珠导轨
three-section ball rail

(A)*16
(B)*16




× 2

(E)*8
(M)*8



1


(D)*2
(E)*16



× 2

3

(A)*8 (J)*6
(B)*8 (K)*6
(C)*6 (L)*1




2

4


ZH2M-A 2.4米高脚电视柜

安装方法/
Installation method




二合一 two-in-one

(E)*8
(H)*6



5


(D)*2
(E)*16



(D) 主轨
Main track

6


(A)*12
(B)*12
(G)*2




7

ZH2M-A 2.4米高脚电视柜

安装方法/ Installation method




- (A)*36
- (B)*36
- (C)*20




8

- (I)*4
- (N)*2



9



10




LINSY 林氏家居

安装示意图/Assembly Instruction

产品名称 Model NO.	ZH2M-A 2米高脚电视柜
产品规格 Specification	2005*398*520mm
安装工具 Tool	安装人数 Installer



注：为保证设计效果，部分尺寸为定制尺寸，不影响使用。




五金表/Hardware list

(A) *76 二合一螺杆 2-in-1 screw	(B) *76 大三合一锁饼 3-in-1 large lock	(C) *27 木榫08x30mm Wood tenon	(D) *2 三节滚珠导轨10"(DTC) Three-section rail
(E) *51 自攻螺丝M3.5*14mm Tapping screw	(F) *16 层板托5mm shelf support	(G) *2 穿线孔盖 Threading cover	(H) *6 灰色毛毡垫(直径25*3mm) Foot pad
(I) *4 缓冲门较大弯-杯径035 Great bend hinge	(J) *6 锤母M8*15 Hammer nut	(K) *6 斜边内六角螺杆-M8x50 Beveled hexagon socket head screw	(L) *1 内六角扳手5mm Hexagon wrench
(M) *8 小角码-(14*21*1.5mm) Small bracket	(N) *2 消音磁碰 Magnetic catch		

部件表/Parts List

编号NO.	名称Name	规格(mm) Specification	数量QTY	材质Material
①	面板Top panel	2005*398*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
②	底板Bottom board	2005*398*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
③	左右侧板Left and right side panels	337*397*15	2	无醛定向刨花板 Aldehyde-free directional particleboard
④	左中侧板Middle side board(L)	337*363*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
⑤	中中侧板Middle side board	337*309*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
⑥	右中侧板Middle side board(R)	337*363*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
⑦	脚组立Leg assembly	150*357*45	3	无醛定向刨花板 Aldehyde-free directional particleboard
⑧	立水Standing water	835*50*15	2	无醛定向刨花板 Aldehyde-free directional particleboard
⑨	背板1Back board 1	486*337*15	2	无醛定向刨花板 Aldehyde-free directional particleboard
⑩	背板2Back board 2	971*337*15	1	无醛定向刨花板 Aldehyde-free directional particleboard
⑪	左门板组立Door board assembly(L)	482*333*30	1	无醛定向刨花板+橡胶木 Aldehyde-free directional particleboard+Rubber wood
⑫	右门板组立Door board assembly(R)	482*333*30	1	无醛定向刨花板+橡胶木 Aldehyde-free directional particleboard+Rubber wood
⑬	左抽屉面板组立Drawer's board assembly(L)	482*333*30	1	无醛定向刨花板+橡胶木 Aldehyde-free directional particleboard+Rubber wood
⑭	右抽屉面板组立Drawer's board assembly(R)	482*333*30	1	无醛定向刨花板+橡胶木 Aldehyde-free directional particleboard+Rubber wood
⑮	抽屉侧板Drawer's sideboard	290*206*15	4	无醛定向刨花板 Aldehyde-free directional particleboard
⑯	抽屉后板Drawer's Back board	452*206*15	2	无醛定向刨花板 Aldehyde-free directional particleboard
⑰	抽屉底板Drawer's Bottom board	432*300*5	2	ENF级纤维板 ENF grade fiberboard




编号NO.	名称Name
①	面板Top panel
②	底板Bottom board
③	左右侧板Left and right side panels
④	左中侧板Middle side board(L)
⑤	中中侧板Middle side board
⑥	右中侧板Middle side board(R)
⑦	脚组立Leg assembly
⑧	立水Standing water
⑨	背板1Back board 1
⑩	背板2Back board 2
⑪	左门板组立Door board assembly(L)
⑫	右门板组立Door board assembly(R)
⑬	左抽屉面板组立Drawer's board assembly(L)
⑭	右抽屉面板组立Drawer's board assembly(R)
⑮	抽屉侧板Drawer's sideboard
⑯	抽屉后板Drawer's Back board
⑰	抽屉底板Drawer's Bottom board

ZH2M-A 2米高脚电视柜


安装方法/ Installation method

阀门开关(下压为开)
Valve switch
(press down to open)




注: 先将A与B拆下来
Note: remove a and B first



侧板
side board





抽屉侧板
sideboard
of the drawer





注: 将B对准A后推进去
Note: align B with a
and push it in
三节滚珠导轨
three-section ball rail



× 2





1



× 2

2


3



4


ZH2M-A 2米高脚电视柜

安装方法/
Installation method




二合一 two-in-one

(E)*8
(H)*6




5

(D)*2
(E)*16



6



(A)*12
(B)*12
(G)*2



7

ZH2M-A 2米高脚电视柜

安装方法/ Installation method




调节上下
Adjust up and down

调节左右
Adjust left and right

调节前后
Before and after adjustment


门铰 Hinge

- (A)*36
- (B)*36
- (C)*20



8

- (I)*4
- (F)*2



9

10

